

# Akai MPD218 USB Pad Controller



Akai MPD218 USB/MIDI Pad.

16 Thick Fat backlit MPC pads  
48 assignable pads accessible via 3 banks  
18 assignable 360-degree potentiometers accessible via 3 banks  
MPC Note Repeat and Full Level  
iOS compatible using the Camera Connection Kit (sold separately)  
16 configurable presets  
USB powered, no AC adapter required  
Includes Ableton Live Lite, Akai Pro MPC Essentials, Sonivox Big Bang Cinematic Percussion and Big Bang Universal Drums

**Price:** \$140.00

***Customer Service Is Our Top Priority!***

---

# Akai MPD226 USB Pad Controller



Akai MPD226 USB/MIDI Pad.

16 Thick Fat RGB illuminated velocity and pressure sensitive MPC pads  
64 assignable pads accessible via 4 banks  
4 assignable faders, 4 assignable Q-Link knobs, 4 assignable Q-Link buttons  
36 assignable controls accessible via 3 banks  
Classic MPC Note Repeat, MPC Swing, 16 Level, Full Level and Tap Tempo  
30 presets total, with configurations for most popular DAWs  
iOS compatible using the Camera Connection Kit (sold separately)  
MIDI In and Out jacks for controlling external gear  
Dedicated Transport controls  
Includes Ableton Live Lite, Akai Pro MPC Essentials, Sonivox Big Bang  
Cinematic Percussion and Big Bang Universal Drums

**Price:** \$249.00

***Customer Service Is Our Top Priority!***